


SWS1320

OWNER'S MANUAL




PARTS LIST

B1	Base	2	B8	Door	1
B2	Left Side	1	B9	Base Front Panel	1
B3	Right Side	1	B10	Base Left Part	1
B4	Back	1	B11	Base Right Part	1
B5	Doorframe	1	a	Screws ST6.3x12 mm	16+1
B6	Bottom Shelf	1	b	Screws ST6.3x16 mm	12+1
B7	Shelf	4	c	Adjustable Feet	4

FOR YOUR SAFETY
PLEASE READ THESE INSTRUCTIONS CAREFULLY
AND RETAIN THEM FOR FUTURE USE.



ASSEMBLY



BALL BEARING DRAWER SLIDES: If it becomes necessary to remove drawers, follow these drawer removal instructions:

- A) Ball bearing slides have black retaining clips. To remove drawer, the retaining clips need to be released by pushing lever up or down simultaneously, and pulling drawer out.
- B) To re-install drawers, simply place drawer onto slides and push in fully.

