


SWS1319

OWNER'S MANUAL




PARTS LIST

A1	Base	2	A9	Left Door	1
A2	Left Side	1	A10	Right Door	1
A3	Right Side	1	A11	Base Front Panel	1
A4	Left Back	1	A12	Base Left Part	1
A5	Right Back	1	A13	Base Right Part	1
A6	Doorframe	1	a	Screws ST6.3x12 mm	16+1
A7	Bottom Shelf	1	b	Screws ST6.3x16 mm	12+1
A8	Shelf	4	c	Adjustable Feet	4

FOR YOUR SAFETY
PLEASE READ THESE INSTRUCTIONS CAREFULLY
AND RETAIN THEM FOR FUTURE USE.



ASSEMBLY



BALL BEARING DRAWER SLIDES: If it becomes necessary to remove drawers, follow these drawer removal instructions:

- A) Ball bearing slides have black retaining clips. To remove drawer, the retaining clips need to be released by pushing lever up or down simultaneously, and pulling drawer out.
- B) To re-install drawers, simply place drawer onto slides and push in fully.

