

WHEEL CHOCKS

OWNER'S MANUAL

HOW TO USE

Your wheel chocks have been designed to be used in conjunction with lifting equipment to help provide safe and stable lifting conditions. Wheel chocks are not support devices and should not be used to raise or to support/secure a vehicle permanently. Please read and understand the following instructions and warnings. Failure to do so may result in personal injury and/or property damage.

1. Place the automatic transmission selector in park or place the manual shift selector in gear with the hand-brake engaged.
2. To prevent further vehicle movement wheels should be securely blocked with wheel chocks.
3. Always use wheel chocks in pairs, one pair per tyre. If more than one tyre is to be blocked use additional pairs of wheel chocks.
4. Always position the wheel chocks so each is centred on the tread of the tyre. Off centre positioning could cause sudden instability resulting in personal injury and/or property damage.

WARNINGS

Wheel chocks are designed to be used only on hard level surfaces capable of sustaining the load. Do not attempt to raise the vehicle by driving on to the wheel chocks. Use common sense and caution when working on or around a vehicle that has been lifted. This product is intended to be used on cars, vans and light trucks only. Failure to heed these warnings could result in personal injury and/or property damage.

FOR YOUR SAFETY
PLEASE READ THESE INSTRUCTIONS CAREFULLY
AND RETAIN THEM FOR FUTURE USE.

